

Universal Travel Adapter

This device is fitted with a safety preventing more than one plug from being used at the same time, the 3 plugs must therefore be used separately.

Please note: this adapter does not transform the current.



UK



Europe



USA



Australia,
China

1) For an English type plug:

- TO OPEN:**
- Turn the grooved plastic ring until the arrow is pointing towards the "UK" marking.
 - When the pointer is in front of the "UK" marking, this means that the plug is ready for use.
- TO CLOSE:**
- Turn the grooved plastic ring until the pointer has returned to its original position.
 - The plug's prongs then retract automatically into the casing.

2) For an EURO type plug:

- TO OPEN:**
- Turn the grooved plastic ring until the arrow is pointing towards the "EURO" marking.
 - When the pointer is in front of the "EURO" marking, this means that the plug is ready for use.
- TO CLOSE:**
- Turn the grooved plastic ring until the pointer has returned to its original position.
 - The plug's prongs then retract automatically into the casing.

3) For an US/AUS type plug:

- TO OPEN:**
- Turn the grooved plastic ring until the arrow is pointing towards the "US/AUS" marking.
 - When the pointer is in front of the "US/AUS" marking, this means that the plug is ready for use.
 - Then incline the prongs or leave them straight (according to country) before plugging into a socket.
- TO CLOSE:**
- Turn the grooved plastic ring until the pointer has returned to its original position.
 - The plug's prongs then retract automatically into the casing.

4) You can plug this into any available power outlet and then connect your device to the universal adaptor. If the indication light shows red, it indicates that universal adaptor is working.