# Operating Instructions RoadWarrior Portable Projection Screen by Draper

# ♠ Caution

- Read instructions through completely before proceeding, and save for future reference.
- ② Nothing should be fastened to screen case or viewing surface.
- 3 Do not write on viewing surface.
- 4 This screen is for indoor use only.
- ⑤ Screen must rest on a flat surface. Do not use on slanted or uneven floors
- 6 Do not use solvents or abrasives for cleaning.
- ① Beware of pinching hands and fingers.

**NOTE:** Screen has been thoroughly inspected and tested at factory and found to be operating properly prior to shipment.

# Setting Up the Screen

① Rotate legs (attached to bottom) until they are perpendicular to screen case (see Fig. 1).



② Rotate carrying strap so it does not interfere with opening case. You can




Figure 2 (side view)

- 3 Unsnap and open screen case.
- 4 Grasp handle marked "Lift Here" (see Fig. 3), and slowly raise screen to desired height. Keep screen dowel level while raising.



Figure 3


## Collapsing the Screen

① Generally reverse procedures used for screen setup.



411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999 www.draperinc.com ■ fax 765-987-7142





#### Screen will not fully extend:

Make sure the screen surface is not "catching" on anything. Make sure case lid is fully open.

#### Screen will not close:

Check roller and scissors to make sure nothing is interfering with their operation.

### Screen tips forward or backward:

Make sure legs are perpendicular to screen case. If they are, screen may be located on too severe an incline.

## Snaps will not open:

Press gently down on screen case just above each snap while opening.

#### Snaps will not close:

Press gently down on screen case just above each snap while closing.

Carrying strap will not rotate out of the way so case will open:

Loosen or remove carrying strap altogether (see below).

